

ILLUMINATION SETTING

- ❑ CANNOT CHANGE GEARS DURING SETTING
When in ILLUMINATION SETTING MODE, pressing the buttons will NOT change gears, but ONLY change illumination settings




CAUTION

- ❑ DO NOT PUSH ESS BUTTONS WHILE TURNING IGNITION ON
Pressing the ESS button while turning ON IGNITION may accidentally activate SETTING MODE

ILLUMINATION SETTING MODE

- Press [B]、[R] on the ESS while the IGNITION is OFF. Keep the buttons depressed, then turn the vehicle IGNITION switch ON. Flashing [B] and [D] indicates SETTING MODE.

Press [B]、[R]
while turning
IGNITION ON




※If the start up demonstration begins, the unit is still in NORMAL MODE so please try the process over again.

ILLUMINATION SETTING PROCEDURES

- Illumination color can be changed in ILLUMINATION SETTING MODE. Make sure the [B] and [D] switches are flashing to confirm setting mode. Follow the steps below to change settings:

Press [R] : L E D COLOR CHANGE
GREEN → AQUA → BLUE → PURPLE → RED → WHITE → YELLOW
Press [N] : L E D BRIGHTNESS UP
Press [D] : L E D BRIGHTNESS DOWN
Press [B] : Confirm Setting, End Setting



- Press [B] to confirm selection.
Pressing [B] will end SETTING MODE and return to Standard Mode. After ending, the startup demonstration will begin.

※Settings will remain even when IGNITION is turned OFF or if the unit is disconnected.